

CPD-200SF/200SFT

SERVICE MANUAL

CPD-200SF

US Model

Canadian Model

ES Model

Chassis No. SCC-K17B-A

Australian Model

Chassis No. SCC-K17D-A


CPD-200SFT

AEP Model

UK Model

Chassis No. SCC-K17C-A

Multiscan **200sf**



X2R CHASSIS

SPECIFICATIONS

Picture tube	0.25 mm aperture grille pitch 17 inches measured diagonally 90-degree deflection	Deflection frequency	Horizontal: 30 to 80 kHz Vertical: 50 to 120 Hz
Viewable image size	Approx. 327 × 241 mm (w/h) (12 ⁷ / ₈ × 9 ¹ / ₂ inches) 15.9" viewing image	AC input voltage/current	100 to 240 V, 50 – 60 Hz, 2 – 1 A
Logical resolution	Horizontal: Max. 1280 dots Vertical: Max. 1024 lines	Dimensions	Approx. 406 × 426.5 × 451 mm (w/h/d) (16 × 16 ⁷ / ₈ × 17 ⁷ / ₈ inches)
Physical resolution	Horizontal: Max. 1280 dots Vertical: Max. 1024 lines	Mass	Approx. 19 kg (41 lb 14 oz)
Standard image area	Approx. 312 × 234 mm (w/h) (12 ³ / ₈ × 9 ¹ / ₄ inches)	Design and specifications are subject to change without notice.	

TRINITRON® COLOR COMPUTER DISPLAY
SONY®



DIAGNOSIS

	Power Saving LED	Power LED
Failure	Blink	Blink

Aging Mode : Raster aging During Power Save, press "POWER switch" button for longer than 2 seconds.
 Self Test : OSD color-bar indication During Power Save, press "POWER switch" button for longer than 8 seconds.

TIMING SPECIFICATION

PRIMARY MODE MODE AT PRODUCTION	MODE 1	MODE 2	PRIMARY MODE 3	MODE 4	MODE 5	MODE 6	MODE 7	MODE 8	MODE 9	MODE 10	MODE 11
RESOLUTION	800 X 600	832 X 624	1024 X 768	1024 X 768	1152 X 870	1280 X 1024	640 X 480	640 X 350	720 X 400	800 X 600	1024 X 768
CLOCK	49.500 MHz	57.300 MHz	78.750 MHz	80.000 MHz	100.000 MHz	135.000 MHz	25.175 MHz	25.175 MHz	28.322 MHz	56.250 MHz	94.500 MHz
— HORIZONTAL —											
H-FREQ	46.875 kHz	49.740 kHz	60.023 kHz	60.241 kHz	68.681 kHz	79.976 kHz	31.469 kHz	31.469 kHz	31.469 kHz	53.674 kHz	68.677 kHz
	usec	usec	usec	usec	usec	usec	usec	usec	usec	usec	usec
H. TOTAL	21.333	20.105	16.660	16.600	14.560	12.504	31.778	31.778	31.777	18.631	14.561
H. BLK	5.172	5.585	3.657	3.800	3.040	3.022	6.356	6.356	6.355	4.409	3.725
H. FP	0.323	0.558	0.203	0.400	0.320	0.119	0.636	0.636	0.636	0.569	0.508
H. SYNC	1.616	1.117	1.219	1.200	1.280	1.067	3.813	3.813	3.813	1.138	1.016
H. BP	3.232	3.909	2.235	2.200	1.440	1.837	1.907	1.907	1.907	2.702	2.201
H. ACTIV	16.162	14.520	13.003	12.800	11.520	9.481	25.422	25.422	25.422	14.222	10.836
— VERTICAL —											
V. FREQ(HZ)	75.000 Hz	74.572 Hz	75.029 Hz	74.927 Hz	75.062 Hz	75.025 Hz	59.940 Hz	70.086 Hz	70.087 Hz	85.061 Hz	84.997 Hz
	lines	lines	lines	lines	lines	lines	lines	lines	lines	lines	lines
V. TOTAL	625	667	800	804	915	1066	525	449	449	631	808
V. BLK	25	43	32	36	45	42	45	99	49	31	40
V. FP	1	1	1	3	3	1	10	37	12	1	1
V. SYNC	3	3	3	3	3	3	2	2	2	3	3
V. BP	21	39	28	30	39	38	33	60	35	27	36
V. ACTIV	600	624	768	768	870	1024	480	350	400	600	768
— SYNC —											
INT(G)	NO	NO	NO	NO	NO	NO	NO	NO	NO	NO	NO
EXT(H/V)/POLARITY	YES P/P	YES N/N	YES P/P	YES N/N	YES N/N	YES P/P	YES N/N	YES P/N	YES N/P	YES P/P	YES P/P
EXT(GS)/POLARITY	NO	NO	NO	NO	NO	NO	NO	NO	NO	NO	NO
INT/NON INT	NON INT	NON INT	NON INT	NON INT	NON INT	NON INT	NON INT	NON INT	NON INT	NON INT	NON INT

96.8.30 VER.

Power Saving Function

This monitor meets the power saving guidelines set by the International ENERGY STAR Program as well as the more stringent TCO92 803299 (NUTEK) guidelines. It is capable of reduced power consumption when used with a computer equipped with Display Power Management Signaling (DPMS). By sensing the absence of the sync signal coming from the computer, it will reduce the power consumption as follows:

CAUTION: The Power Saving function will automatically put the monitor into Active-off state if the power switch is turned on without any video signal input. Once the horizontal and vertical syncs are sensed, the monitor will automatically return to its Normal operation state.

	State	Power consumption	Required resumption time	POWER indicator	POWER SAVING indicator
1	Normal operation	100%	—	green on	off
2	Suspend (1st step of power saving)	approx. 10%	approx. 3 sec.	green on	orange on
3	Active-off (2nd step of power saving)	approx. 7%	approx. 10 sec.	off	orange on
4	Power-off	approx. 7%	—	off	off

If you want the power consumption to be 0W, unplug the power cord.

SAFETY CHECK-OUT

(US Model only)

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
5. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
6. Check the line cords for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
7. Check the B+ and HV to see if they are specified values. Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
8. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC Leakage. Check leakage as described below.




Fig. A. Using an AC voltmeter to check AC leakage.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOMs that are suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)

WARNING!!

NEVER TURN ON THE POWER IN A CONDITION IN WHICH THE DEGAUSS COIL HAS BEEN REMOVED.

SAFETY-RELATED COMPONENT WARNING!!
COMPONENTS IDENTIFIED BY SHADING AND MARK Δ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL FOR SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL FOR SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

AVERTISSEMENT!!

NE JAMAIS METTRE SOUS TENSION QUAND LA BOBINE DE DEMAGNETISATION EST ENLEVÉE.

ATTENTION AUX COMPOSANTS RELATIFS À LA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET UNE MARQUE Δ SONT CRITIQUES POUR LA SÉCURITÉ. NE LES REMPLACER QUE PAR UNE PIÈCE PORTANT LE NUMÉRO SPECIFIÉ. LES RÉGLAGES DE CIRCUIT DONT L'IMPORTANCE EST CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT SONT IDENTIFIÉS DANS LE PRÉSENT MANUEL. SUIVRE CES PROCÉDURES LORS DE CHAQUE REMPLACEMENT DE COMPOSANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNEMENT EST SUSPECTÉ.


TABLE OF CONTENTS

<i>Section</i>	<i>Title</i>	<i>Page</i>
1. GENERAL	5
2. DISASSEMBLY		
2-1.	Cabinet Removal	7
2-2.	Service Position	7
2-3.	A Board Removal	7
2-4-1.	D Board Removal (CPD-200SF)	8
2-4-2.	D Board Removal (CPD-200SFT)	8
2-5-1.	Picture Tube Removal (CPD-200SF)	9
2-5-2.	Picture Tube Removal (CPD-200SFT)	9
3. SAFETY RELATED ADJUSTMENT	10
4. ADJUSTMENTS	11
5. DIAGRAMS		
5-1.	Block Diagram (with Frame Schematic Diagram)	13
5-2.	Circuit Boards Location	16
5-3.	Schematic Diagrams and Printed Wiring Boards ...	16
(1)	Schematic Diagram of D Board	17
(2)	Schematic Diagram of A Board	25
5-4.	Semiconductors	28
6. EXPLODED VIEWS		
6-1-1.	Chassis (CPD-200SF)	29
6-1-2.	Chassis (CPD-200SFT)	30
6-2.	Packing Materials	31
7. ELECTRICAL PARTS LIST	32

Adjustments

When one of the preset-type signals is input, no picture adjustment is necessary. You can, however, adjust the picture to your preferences by following the procedure described below. You can adjust the all items on the OSD (On Screen Display).

Control Panel




- Before adjusting the items, turn on the unit and feed the video signal from the connected computer/work station.
- Adjustments will be stored automatically.

Adjusting the Picture Brightness

The adjustment data becomes the common setting for all input signals.

- 1 Press the button. The "CONTRAST/BRIGHTNESS" OSD appears.



- 2 Press the buttons to adjust picture brightness.
 - ← ... for less brightness
 - ... for more brightness


The "CONTRAST/BRIGHTNESS" OSD disappears 3 seconds after you release the buttons.

To reset, press the RESET button while the OSD is on.

Adjusting the Picture Contrast

The adjustment data becomes the common setting for all input signals.

- 1 Press the button. The "CONTRAST/BRIGHTNESS" OSD appears.



- 2 Press the buttons to adjust picture contrast.
 - ↑ ... for more contrast
 - ↓ ... for less contrast


The "CONTRAST/BRIGHTNESS" OSD disappears 3 seconds after you release the buttons.

To reset, press the RESET button while the OSD is on.


Adjusting the Picture Centering

The adjustment data becomes the individual setting for each input signal received.

- 1 Press the CENTER button. The "CENTER" OSD appears.




- 2 For vertical adjustment Press the buttons.



- ↑ ... to move up
- ↓ ... to move down

For horizontal adjustment Press the buttons.



- ← ... to move left
- ... to move right

To erase the "CENTER" OSD, press the CENTER button again. The "CENTER" OSD automatically disappears 10 seconds after you release the buttons.

To reset, press the RESET button while the OSD is on.


*The horizontal and vertical frequencies for each input signal received appear on the "CONTRAST/BRIGHTNESS" OSD.

Adjustments

Adjusting the Picture Size

The adjustment data becomes the individual setting for each input signal received.

- 1 Press the SIZE button. The "SIZE" OSD appears.




- 2 For vertical adjustment Press the buttons.



- ↑ ... to enlarge
- ↓ ... to diminish

For horizontal adjustment Press the buttons.



- ← ... to diminish
- ... to enlarge


To erase the "SIZE" OSD, press the SIZE button again. The "SIZE" OSD automatically disappears 10 seconds after you release the buttons.

To reset, press the RESET button while the OSD is on.

Adjusting the Picture Rotation

The adjustment data becomes the common setting for all input signals.

- 1 Press the GEOM button. The "GEOMETRY" OSD appears.



- 2 Press the buttons.
 - ↑ ... to rotate clockwise
 - ↓ ... to rotate counterclockwise




To erase the "GEOMETRY" OSD, press the GEOM button again. The "GEOMETRY" OSD automatically disappears 10 seconds after you release the buttons.

To reset, press the RESET button while the OSD is on.

Adjusting the Pincushion

The adjustment data becomes the individual setting for each input signal received.


- 1 Press the GEOM button. The "GEOMETRY" OSD appears.




- 2 Press the buttons.



- ← ... to diminish the picture sides



- ... to expand the picture sides




To erase the "GEOMETRY" OSD, press the GEOM button again. The "GEOMETRY" OSD automatically disappears 10 seconds after you release the buttons.

To reset, press the RESET button while the OSD is on.

Setting the Color Temperature

The selected color temperature becomes the common setting for all input signals.

- 1 Press COLOR button.
The "COLOR TEMPERATURE" OSD appears.



- 2 Adjust with the \odot \leftarrow/\rightarrow and \odot \uparrow/\downarrow buttons.

To select 5000K or 9300K

Press \odot \leftarrow/\rightarrow buttons.

The selected color temperature is indicated in yellow.



\leftarrow ... to select 5000K

\rightarrow ... to select 9300K

To obtain the desired color temperature between 5000K and 9300K

Press \odot \uparrow/\downarrow buttons.



\uparrow ... for higher temperature

\downarrow ... for lower temperature

Your most recent adjusted color temperature will be recalled by pressing \odot \uparrow/\downarrow button.

To erase the "COLOR TEMPERATURE" OSD, press the COLOR button again.

The "COLOR TEMPERATURE" OSD automatically disappears 10 seconds after you release the buttons.

To reset, press the RESET button while the OSD is on.

Resetting the Adjustment Data to Factory-preset Levels

To reset an adjustment item

Press the button of the adjustment item you want to reset, and then press the RESET button before the OSD (On Screen Display) disappears.

To reset all adjustment data at once (for the received signal)

Press the RESET button with something like a pen for 1 second when no OSD is shown.



To reset all adjustment data to factory-preset levels

Press and hold the RESET button for more than 2 seconds. All adjustment data are reset to factory-preset levels.



This section may help you isolate a problem and as a result, eliminate the need to contact technical support, allowing continued productivity.

No picture

- If neither the \odot POWER indicator nor the POWER SAVING indicator is lit
 - Check that the power cord is properly connected.
 - Check that the \odot POWER switch is in the "ON" position.
- If the POWER SAVING indicator is lit
 - Check that your computer power switch is in the "ON" position.
 - The monitor will recover when you press any key on the keyboard of the computer.
 - Check that the video cable is properly connected.
 - Ensure that no pins are bent or pushed in the HD15 connector of the cable.
 - Check that the video card is seated completely in a proper bus slot.
 - Check that the video sync signal is within that specified for the monitor.
 - If using a Mac system, check that a proper HD15 - D15 adapter is provided to work correctly with your Mac.
 - The monitor has a self-diagnose function. After turning the \odot POWER switch off, press and hold the \odot POWER switch for 8 seconds. If the \odot POWER indicator blinks, the screen turns white, and the color bars appear, then these conditions show that the monitor is operating normally. Contact the maker of the computer to which the monitor is connected.
- If the \odot POWER and the POWER SAVING indicators are both flashing
 - There is a potential monitor failure. Contact your dealer.

If the message of "OUT OF SCAN RANGE" appears on the screen

- Check that the video sync signal is specified for the monitor.

Picture is scrambled

- Check your graphics board manual for the proper monitor setting on your Multiscan 100sf/200sf.
- Check this manual and confirm that the graphic mode and the frequency at which you are trying to operate is supported. Even within the proper range some video boards may have a sync pulse that is too narrow for the monitor to sync correctly.

Color is not uniform

- If the monitor is close to any potential sources of magnetic fields such as a speaker, or you turn the monitor while the \odot POWER switch is in the "ON" position, color may not be uniform. Trip the \odot POWER switch once to activate the Auto-degauss cycle*.

Picture is flickering

- If the refresh rate is not appropriate, the picture may flicker. Set the refresh rate of the non-interlace mode as high as possible on the computer. For details on how to set the refresh rate, consult the dealer of your computer or video board.

Screen image is not centered or sized properly

- Adjust the "CENTER," "SIZE," or "GEOMETRY" on the OSD (pages 5, 6).
- Some video modes do not fill the screen to the edge of the monitor. There is no single answer to solve the problem. There is a tendency to have this problem on higher refresh timings and Macintosh video timings.

Picture is fuzzy

- Adjust the "CONTRAST" and "BRIGHTNESS" on the OSD (page 5). We have come across several brands of SVGA boards that have an excessive video output level which creates a fuzzy picture at max contrast.
- Trip the \odot POWER switch once to activate the Auto-degauss cycle*.

Picture bounces or has wavy oscillations

- Isolate and eliminate any potential sources of electric or magnetic fields. Common causes for this symptom are electric fans, fluorescent lighting, laser printers, and so on.
- If you have another monitor close to this monitor, increase the distance between them to reduce the interference.
- Try plugging the monitor into a different AC outlet, preferably on a different circuit.
- Try the monitor on a completely different computer in a different room.

Picture appears to be ghosting

- Eliminate the use of video cable extension cables and/or video switch boxes if this symptom occurs. Excessive cable length or weak connections can produce this symptom.

A fine horizontal line (wire) is visible

- This wire stabilizes the vertically striped Aperture Grille (page 8). This Aperture Grille allows more light to pass through to the screen giving the Trinitron CRT more color and brightness.

Wavy or elliptical (moire) pattern is visible

- Due to the relationship between resolution, monitor AG pitch and the pitch of some image patterns, certain screen backgrounds, especially gray, sometimes show moire. This can only be eliminated by changing your desktop pattern.

Just after turning the monitor on, a "boon" noise is heard

- Just after turning the monitor on, a noise may be heard for about 3 seconds. This noise is not failure, it is caused by the auto-degauss cycle*.


* The Auto-degauss function demagnetizes the metal frame of the CRT to obtain a neutral field for uniform color reproduction. If a second degauss cycle is needed, allow a minimum interval of 20 minutes for the best result.

• If the problem persists, call your authorized Sony dealer from a location near your monitor.


• Note the model name and the serial number of your monitor. Also note the make and name of your computer and video board.

SECTION 2 DISASSEMBLY


2-1. CABINET REMOVAL




2-2. SERVICE POSITION




2-3. A BOARD REMOVAL




**2-4-1. D BOARD REMOVAL
(CPD-200SF)**




**2-4-2. D BOARD REMOVAL
(CPD-200SFT)**



**2-5-1. PICTURE TUBE REMOVAL
(CPD-200SF)**




**2-5-1. PICTURE TUBE REMOVAL
(CPD-200SFT)**



• REMOVAL OF ANODE-CAP


NOTE: Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon painted on the CRT, after removing the anode.

• REMOVING PROCEDURES



• HOW TO HANDLE AN ANODE-CAP

- Don't hurt the surface of anode-caps with sharp shaped material!
- Don't press the rubber hardy not to hurt inside of anode-caps!
A material fitting called as shatter-hook terminal is built in the rubber.
- Don't turn the foot of rubber over hardy!
The shatter-hook terminal will stick out or hurt the rubber.



SECTION 3 SAFETY RELATED ADJUSTMENT

When replacing or repairing the shown below table, the following operational checks must be performed as a safety precaution against X-rays emissions from the unit.

	Part Replaced (☒)
HV ADJ	RV501

	Part Replaced (☑)
HV Regulator Circuit	D board IC501, Q505, Q510, D505, D512, D516, C506, C526, C531, C532, C535, C558, R512, R532, R535, R536, R537, R538, RV501, T501
HV Protector Circuit	D board IC701, D800, D801, C709, C803, C804, R706, R800, R804, R808, T501 • Mounted D board
Beam Current Protector Circuit	D board IC701, IC901, Q801, D517, D802, C537, C806, C807, C912, R539, R540, R541, R542, R809, R810, R811, R812, R816, R933, T501 • Mounted D board

※ Confirm one minute later turning on the power.

● HV Protector Check

Confirm that the HV protector circuit works and CRT screen disappearing when apply the voltage as shown below between Anode of D800 on D board and GND using an external DC Power Supply.

- Standard voltage : Anode of D800 less than 28.90 V DC

Check Condition

- Input voltage : 120 V AC
- Input signal : Dot at 60.0 kHz
(VESA 1024 x 768)
- Beam control : BRT and CONT → Minimum

● Beam Protector Check

(1) Software logic circuit

- 1) Confirm that the Beam current protector by software logic works and CRT screen disappearing when connect 150 kΩ resistor in parallel with R542 on D board.

(2) Hardware logic circuit

- 1) Using an external DC Power Supply, applying voltage of 5.00 V to between ① pin of IC901 D board and GND.
- 2) Confirm that the Beam current protector circuit by hardware logic works and CRT screen disappearing when shorted to between ② pin of T501 and GND.

Check Condition

- Input voltage : 120 V AC
- Input signal : All white at 60.0 kHz
(VESA 1024 x 768)
- Beam control : CONT and BRT → Maximum

● B+ Voltage Check

Standard voltage : 169.0 ± 1.0 V DC

Check Condition

- Input voltage : 120 V AC
- Note : Use NF power supply or make sure that distortion factor is 3% or less.
- Input signal : Cross hatch at 80.0 kHz
- Beam control : CONT, BRT → Maximum

SECTION 4 ADJUSTMENTS


● Landing Rough Adjustment

1. Enter the full white signal.
 2. Set the contrast to "CONT"=255.
 3. Make the screen monogreen.
- Note: Off the outputs from R ch and B ch of SG.
4. Reverse the DY, and adjust coarsely the purity magnet so that a green raster positions in the center of screen.
 5. Moving the DY forward, adjust so that an entire screen becomes monogreen.
 6. Adjust the tilt of DY, and fix lightly with a clamp.
- Note: "TILT" shall be set at 0.


● Landing Fine Adjustment

1. Put the set inside the Helmholtz coil.
 2. Input the single green signal and set the CONT control to MAX.
- Note: Set to $\Sigma 1k=300 \mu A$ with the signal green signal, and after aging for about 30 minutes, adjust so that it is exactly this value.
3. Demagnetize the CRT surface with the hand degausser, and perform auto degaussing.
- Note: Adjust in a non-magnetic field.
4. Attach the wobbling coil to the designated part of the CRT neck.
 5. Attach the sensor of the landing adjustment unit on the CRT surface.
 6. Adjust the DY position and purity, and the DY tilt, and landing of the center and 4 corners with the landing checker.

Purity



<Specification>




Adjust the green of corners ① to ④, and center ⑥ to $\pm 5 \mu m$, and red and blue to within $\pm 7 \mu m$ of green, and the difference between red and blue to within $\pm 10 \mu m$.
Adjust the green of ⑤ and ⑦ to within $\pm 10 \mu m$, and red and blue to within $\pm 7 \mu m$ of green, and the difference between red and blue to within $\pm 10 \mu m$.


(Set each corner to 1st frame of the crosshatch.)

7. For the up/down and left/right swing, swing the DY and insert a wedge so that the up and down pins are equal at the top and bottom and the horizontal trapezoid is equal at the left and right. Insert the wedge firmly so that the DY does not shake.


Signals: Inverted crosshatch signal (monochrome G) and crosshatch signals (B and R)



"a" and "b" must be equal, and "c" and "d" must be almost equal.




A and B, or A' and B' must be almost equal.



C and D, or C' and D' must be almost equal.

<How to drive in wedges>



Drive in wedges as shown in the left figure, and apply RTV as shown with hatched lines.

← As viewed from a neck side

8. Check the landing of each corner, and if they do not satisfy the specification, paste a Disk-Mg onto the funnel and adjust.


Note:

- (1) Do not paste more than 2 magnets to one corner.
- (2) Paste within 80 to 100 mm from the DY on the diagonal line of the magnet.
- (3) If using the magnet, be sure to demagnetize with the hand degausser and check.
9. Remove the sensor and wobbling coil.
10. Switch the signal to R.G.B., and check that each color is pure.
11. Check that the DY is not tilting, and fix the purity Mg with a white pen.
12. Fasten DY with screw.

Note: Torque $20 \pm 2 \text{ kg-cm}$

CPD-200SF/200SFT

Connect the communication cable of the computer to the connector located on the D board on the monitor. Run the service software and then follow the instruction.



*The parts above (① ~ ③) are necessary for DAS adjustment.

● Convergence Rough Adjustment

1. Enter the white crosshatch signal (white lines on black).
2. Adjust roughly the horizontal and vertical convergence at four-pole magnet.
3. Adjust roughly HMC and VMC at six-pole magnet. Standard: $\pm 0.1\text{mm}$ (in the center of screen)
4. Make rough adjustment of the H direction convergence by using H. STAT VR (RV001 of A board).




Fig. 1





Fig. 2



<6 Pole Magnet>






Fig. 3




Adjust HMC
Fig. 4



Adjust VMC
Fig. 5

● Convergence Specification




MODE	All mode
A	0.24 mm
B	0.32 mm

● White Balance Adjustment Specification

- (1) 9300K
 $x = 0.283 \pm 0.005$
 $y = 0.298 \pm 0.005$
- (2) 5000K
 $x = 0.345 \pm 0.005$
 $y = 0.358 \pm 0.005$

● Vertical and Horizontal Position and Size Specification




MODE	All mode
A	312 mm
B	234 mm

$$a \leq 2.2 \text{ mm}$$


$$b \leq 2.2 \text{ mm}$$

● Focus adjustment


Adjust the focus volume 1 and 2 for the optimum focus.



5-1. BLOCK DIAGRAM (with FRAME SCHEMATIC DIAGRAM)



5-2. CIRCUIT BOARDS LOCATION



5-3. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

- Note:**
- All capacitors are in μF unless otherwise noted. pF: μpF
 - 50 V or less are not indicated except for electrolytic.
 - Indication of resistance, which does not have one for rating electrical power, is as follows.
- Pitch: 5 mm
Rating electrical power 1/4 W (CHIP: 1/10 W)
- All resistors are in ohms.
 - : nonflammable resistor.
 - : fusible resistor.
 - : internal component.
 - : panel designation, and adjustment for repair.
 - All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
 - : earth-ground.
 - : earth-chassis.
 - The components identified by in this basic schematic diagram have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.
 - When replacing components identified by , make the necessary adjustments indicated. (See page 10)
 - When replacing the part in below table, be sure to perform the related adjustment.

	Part replaced ()
HV ADJ	RV501

	Part replaced ()	
HV Regulator Circuit	D board	IC501, Q505, Q510, D512, D516, C506, C526, C531, C532, C535, C558, R512, R532, R535, R536, R537, R538, RV501, T501
	D board	IC701, D800, D801, C709, C803, C804, R706, R800, R808, T501

	Part replaced ()	
Beam Current Protector Circuit	D board	IC701, IC901, Q801, D517, D802, C537, C806, C807, C912, R539, R540, R541, R542, R809, R810, R811, R812, R816, R933, T501

Note: The components identified by shading and mark are critical for safety. Replace only with part number specified.


Note: Les composants identifiés par un trame et une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- All voltages are in V.
- Readings are taken with a 10 M Ω digital multimeter.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerances.
- * : Can not be measured.
- Circled numbers are waveform references.
- : B + bus.
- : B - bus.


(1) Schematic Diagram of D Board

● D BOARD VOLTAGE LIST


Ref.	Pin No.	Voltage [V]	Ref.	Pin No.	Voltage [V]
IC501	1	5.9	IC901	31	0.7
	2	8.9		32	1.9
	3	0		33	2.3
	4	6.9		34	2.3
	5	0.8		35	0
	6	6.9		36	3.9
	7	6.0		37	3.7
	8	5.9		38	0.5
	9	5.9		39	4.3
	10	4.6		40	3.3
	11	5.9		41	2.9
	12	9.2		42	5.1
	13	8.7		43	5.1
	14	5.9		44	5.1
	15	5.7		45	0
	16	5.9		46	5.1
	17	7.8		47	2.4
	18	7.8		48	0.1
	19	7.8		49	5.1
	20	7.8		50	5.1
	21	7.8		51	4.4
	22	7.8		52	*
IC502	1	1.4	Q502	B	1.2
	2	-14.9		C	182.6
	3	0.3		E	0.6
	4	14.7			
IC503	1	1.4	Q503	B	-15.2
	2	1.4		C	-0.1
	3	0.8		E	-15.2
	4	0.8			
IC504	1	10.4	Q504	B	1.2
	2	2.8		C	182.6
	3	6.9		E	0.6
	4	6.9			
IC505	1	47.4	Q505	B	167.3
	2	47.2		C	40.3
	3	40.6			
	4	47.4			
IC601	1	125.5	Q507	B	-0.9
	2	0.1		C	48.1
	3	0			
	4	1.5			
IC650	1	141.0	Q512	G	0
	2	13.3		D	14.2
	3	0.3			
	4	7.1			
IC651	1	14.3	Q513	D	5.1
	2	13.3		D	0
	3	0.3		D	0
	4	7.1		D	14.7
IC652	3	4.3	Q515	B	8.6
	1	15.3		C	12.2
	2	14.6		C	8.4
	3	0.1		B	8.7
IC653	1	4.2	Q516	B	8.7
	2	0.1		B	8.4
	3	0.1			
	4	1.2			
IC701	1	5.5	Q518	G	166.9
	2	5.1		D	48.7
	3	3.2			
	4	5.0		B	9.2
	5	-0.4		C	12.2
	6	0		E	9.0
	7	8.0			
	8	1.6		B	9.2
	9	6.4		E	9.0
	10	4.0		B	10.4
	11	3.5		E	9.9
	12	3.5			
	13	8.0		B	10.4
	14	0.1		E	9.9
	15	4.2			
	16	6.7		B	0.7
17	0.7	C	0.3		
18	0.7				
19	6.5	B	5.1		
20	4.6	D	0		
21	5.1				
22	5.1				
23	8.1	B	3.0		
24	3.5	C	49.8		
25	3.6	E	2.5		
26	3.8				
27	3.8	B	7.1		
28	0.5	C	20.6		
29	4.4	E	7.6		
30	3.6				
31	4.5	B	0		
32	0.1	C	50.0		
33	0.1				
34	3.0	B	7.0		
35	3.0	C	6.5		
36	4.1	E	7.3		
37	4.3				
38	4.1	B	0		
39	4.1	C	0		
40	4.1				
41	4.1				
42	4.0				
IC901	1	8.1	Q653	B	0
	2	4.0		C	12.2
	3	1.7			
	4	2.7		B	0
	5	1.7		C	14.5
	6	2.5			
	7	2.8		B	3.3
	8	2.4		C	0.1
	9	3.2		B	4.3
	10	3.1		C	0
	11	2.3			
	12	1.9		B	0
13	5.1	C	13.3		
14	2.8				
15	4.0	B	6.5		
16	4.2	E	6.5		
17	5.1				
18	5.0	B	6.5		
19	4.8	E	6.5		
20	-0.6				
21	0	B	0.6		
22	5.0	C	0.1		
23	2.4				
24	2.4	B	6.9		
25	5.1	E	6.3		
26	0.1				
27	4.2	B	2.4		
28	4.1	E	3.0		
29	4.1				
30	0.7	B	0		
		C	5.1		



● D BOARD WAVEFORMS



● D BOARD IC502 TDA8172



● D BOARD SEMICONDUCTOR LOCATION

IC	Location
IC501	E-1
IC502	E-3
IC503	A-1
IC504	E-1
IC505	C-4
IC601	A-4
IC650	B-2
IC651	B-4
IC652	C-2
IC653	B-4
IC701	D-1
IC901	C-1
IC902	C-1

TRANSISTOR	Location
Q501	E-4
Q502	E-5
Q503	C-5
Q505	C-6
Q507	C-5
Q510	C-6
Q511	D-2
Q512	C-3
Q513	D-2
Q515	E-2
Q516	E-1
Q518	C-5
Q524	E-3
Q525	D-2
Q526	C-3
Q527	E-1
Q528	E-1
Q529	E-1
Q530	E-2
Q531	E-2
Q532	E-2
Q533	E-2
Q534	E-2
Q535	E-2
Q536	E-2
Q537	E-2
Q538	E-2
Q539	E-2
Q540	E-2
Q541	E-2
Q542	E-2
Q543	E-2
Q544	E-2
Q545	E-2
Q546	E-2
Q547	E-2
Q548	E-2
Q549	E-2
Q550	E-2
Q551	E-2
Q552	E-2
Q553	E-2
Q554	E-2
Q555	E-2
Q556	E-2
Q557	E-2
Q558	E-2
Q559	E-2
Q560	E-2
Q561	E-2
Q562	E-2
Q563	E-2
Q564	E-2
Q565	E-2
Q566	E-2
Q567	E-2
Q568	E-2
Q569	E-2
Q570	E-2
Q571	E-2
Q572	E-2
Q573	E-2
Q574	E-2
Q575	E-2
Q576	E-2
Q577	E-2
Q578	E-2
Q579	E-2
Q580	E-2
Q581	E-2
Q582	E-2
Q583	E-2
Q584	E-2
Q585	E-2
Q586	E-2
Q587	E-2
Q588	E-2
Q589	E-2
Q590	E-2
Q591	E-2
Q592	E-2

DIODE	Location
D402	E-3
D403	E-3
D404	E-3
D405	E-2
D501	C-5
D502	D-5
D503	C-5
D505	C-6
D506	D-3
D507	D-3
D512	C-6
D513	C-4
D516	C-6
D517	E-5
D518	D-5
D524	D-3
D525	C-5
D526	C-5
D527	D-3
D528	D-4
D529	E-4
D530	C-4
D601	B-5
D604	B-4
D606	B-4
D607	B-4
D608	B-4
D609	B-4
D612	B-4
D650	B-3
D651	B-3
D652	A-3
D653	A-3
D654	A-3
D655	B-4
D657	A-3
D658	A-3
D659	B-2
D660	B-2
D701	D-1
D703	E-3
D704	D-1
D800	E-4
D801	E-1
D802	E-1
D803	C-2
D901	B-1
D911	A-1
D913	A-1
D914	B-2
D915	B-2
D916	B-2
D917	B-1
D918	B-2
D920	C-1
D921	A-1

VARIABLE RESISTOR	Location
RV501	E-6


CRYSTAL	Location
X900	B-1

Terminal name of semiconductors in silk screen printed circuit (*)


Device	Printed symbol	Terminal name	Circuit
Transistor	T	Collector Base Emitter	
Discrete semiconductor	-		

NOTE:
The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.

Schematic diagram
D board →



D [POWER DEFLECTION]






● A BOARD SEMICONDUCTOR LOCATION

IC	
IC001	B-2
IC002	A-2
IC003	A-1
IC004	B-3
IC005	A-1
IC006	B-1
IC007	B-1
TRANSISTOR	
Q001	B-3 *
Q002	B-1 ①
Q003	B-1 ①
Q004	B-1 ①
DIODE	
D002	B-1 *
D011	B-2 -
D014	B-3 -
D058	B-2 -
D101	B-1 -
D104	A-3 -
D105	A-3 -
D106	B-3 -
D201	B-1 -
D204	A-3 -
D205	A-3 -
D206	A-3 -
D301	B-2 -
D304	A-3 -
D305	A-2 -
D306	A-3 -
VARIABLE RESISTOR	
RV001	B-3
CRYSTAL	
X1	A-1


— A Board —




Terminal name of semiconductors in silk screen printed circuit (*)

	Device	Printed symbol	Terminal name	Circuit
①	Transistor		Collector Base Emitter	
-	Discrete semiconductor			


Note: The pin name "H2" of "J001" (CRT socket) on the A board is wrong, and it is "H1" in truth.



● A BOARD IC007 HD74HC123AFP





(CRT socket) on
s "H1" in truth.



NOTE:
The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.

(2) Schematic Diagram of A Board








A (VIDEO)

B-553367<U/C>-A..

5 16 17 18 19 20



● A BOARD WAVEFORMS



● A BOARD VOLTAGE LIST

Ref.	Pin No.	Voltage [V]	Ref.	Pin No.	Voltage [V]	
IC001	1	0	IC005	1	10.3	
	2	0		2	3.3	
	3	0		3	3.3	
	4	0		5	1.6	
	5	2.3		6	1.6	
	8	2.3		7	1.7	
	11	2.3		IC006	1	3.7
	12	2.0	2		0.6	
	13	2.4	3		0.6	
	14	1.7	4		4.5	
	15	5.1	6		5.1	
	16	4.6	8		5.1	
	17	5.5	10	0.7		
18	2.1	11	4.5			
19	5.5	12	4.5			
20	2.1	13	0.7			
23	2.2	IC007	1	0.1		
24	5.4		3	4.7		
25	1.1		5	0.1		
26	1.8		6	0		
27	2.0		7	5.1		
28	2.2		9	0.7		
IC002	1		52.0	12	5.1	
	3		52.9	13	4.6	
	5	53.9	14	0		
	8	2.0	15	1.4		
	9	2.1	Q001	B	11.7	
11	2.2	C		337.0		
		E		11.2		
IC003	1	2.1	Q002	B	3.0	
	2	1.8		E	3.7	
	3	0		Q003	B	4.9
	4	-0.5	C		0.7	
	5	-0.1	Q004	B	2.6	
	9	2.4		E	3.0	
	10	2.2		J001	KR	77.3
	11	1.3			KG	82.1
	12	3.5	KB		71.9	
	13	2.2	G2		337.0	
	14	3.5	H1		6.4	
	15	4.7				
	16	4.8				
	17	5.1				
19	0					
20	0					
21	0					
23	2.5					
24	2.9					
IC004	1	1.2				
	2	1.2				
	3	1.2				
	5	1.2				
	7	99.9				
	8	104.1				
	9	92.9				

Schematic diagram


← A board

5-4. SEMICONDUCTORS

HD74HC123AFP



STR-S6708A




IRFI9630
IRFI9630GS
2SB1094-LK
2SB1375
2SC3746
2SC5022-02
2SJ449(1)
2SJ449(2)




2SK1307
2SK1904




GBU4JL-6088




LA6500-FA




ST7272N5B1/CKO




EGP10D
RGP10DG23
RGP10JPKG23
RH-1A




SB340



LM2283N




TDA6103Q/N3




IRFPG50LF21
2SK2077




EGP10GPKG23
MTZJ-T-77-10B
MTZJ-T-77-12B
MTZJ-T-77-20C
MTZJ-T-77-5.1B
MTZJ-T-77-5.6B
RD10ES-B2
RD12ES-B2
RD20ES-B2
RD5.1ES-B2
RD5.6ES-B2
RD7.5ES-B2
1SS119-25
1SS120




SB340L-6489



LM2903M
NJM2903M-T2
NJM4558M
μPC4558G2




TDA8138A
TDA8172




2SC2001-K2
2SC2001-LK




1SS120TD




SE-140N




TDA9105S




2SC2611




1SS226



SNY425




DTC124EKA-T146
2SA1037K-T-146-QR
2SA1162-G
2SB709A-QRS-TX
2SD601A-Q
2SD601A-QRS-TX




2SC3209LK
2SD774-3
2SD774-34




EGP20DL-6349
EL1Z
EL1Z-V1
ERB91-02
GP08D
GP08DPKG23
HSS82
RGP02-20EL-6394
RGP10GPKG23
UF3ML-6505
UG4DL-6506
3DL41A




5TUZ52



SN74HCT04ANS




DTS124ESA
2SA1175-HFE
2SA1309A-QRSTA
2SC2785-HFE
2SC3311A-QRSTA



2SD1640Q,R



SEL1422G-C,D
SEL1922D-C
SG232D-658
SY432W-M-658



SECTION 6 EXPLODED VIEWS


- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

6-1-1. CHASSIS (CPD-200SF)

- | | | | |
|----------------|------------|----------------|------------|
| ● 7-685-648-79 | +BVTP 3X12 | △ 7-682-562-04 | +BVTT 4X10 |
| ▲ 7-685-646-79 | +BVTP 3X8 | ▽ 7-685-650-79 | +BVTP 3X16 |
| ■ 7-685-663-71 | +BVTP 4X16 | ◇ 7-685-659-71 | +BVTP 4X8 |
| ○ 7-682-548-04 | +BVTT 3X8 | | |




REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
1	X-4033-961-1	BEZEL ASSY [for Japan-made set]	2,3	16	*4-047-316-01	SPRING, TENSION	
	X-4034-061-1	BEZEL ASSY [for USA-made set]	2,3	17	△ 1-409-975-12	COIL, DEMAGNETIZATION	
2	4-046-410-21	BUTTON, POWER		18	4-365-808-01	SCREW (5), TAPPING	
3	3-571-801-01	SPRING, COMPRESSION		19	*8-933-208-00	D BOARD, COMPLETE	
4	4-046-427-01	CABINET		20	△ X-4034-327-1	TRANSFORMER ASSY, FLYBACK	
5	4-046-903-01	COVER, SCREW					(NX-4111/J1E4)
6	△ 8-738-709-92	ITC ASSY (17SASK R2) (US/CN)	7-9	21	*4-045-130-01	BRACKET, CABLE	
	△ 8-738-709-91	ITC ASSY (17SASK R3) (ES)	7-9	22	*4-045-131-01	STOPPER, CABLE	
	△ 8-738-713-91	ITC ASSY (17SASK RS1) (AUS)	7-9	23	1-776-975-31	CABEL ASSY (15P DSUB CONNECTOR)	
7	△ 8-738-709-05	PICTURE TUBE 17SASK (US/CN, ES)		24	X-4032-232-1	STAND ASSY, SWIVEL	25-30
	△ 8-738-713-05	PICTURE TUBE 17SASK (AUS)		25	4-046-901-01	SPRING, TENSION	
8	△ 8-451-478-71	DEFLECTION YOKE Y17SAH5-M7		26	*4-043-646-01	HOLDER, STAND	
9	4-040-897-01	SPACER, DY [for USA-made set]		27	4-041-623-01	STOPPER (A)	
	4-050-492-01	SPACER, DY [for Japan-made set]		28	4-046-426-01	COVER, BOTTOM	
10	*4-056-261-01	LABEL, INFORMATION		29	*4-041-625-01	RING, TILT SWIVEL [for Japan-made set]	
		[ES for Japan-made set, U/C for Japan-made set]			*4-041-625-21	RING, TILT SWIVEL [for USA-made set]	
	*4-056-261-11	LABEL, INFORMATION		30	*4-041-621-21	STOPPER (B) [for USA-made set]	
		[AUS for Japan-made set]		31	3-691-950-01	SPACER, P.C.B	
	*4-056-265-01	LABEL, INFORMATION		32	*4-046-894-02	SHIELD, FBT	
		[ES for USA-made set, U/C for USA-made set]		33	4-308-870-00	CLIP, LEAD WIRE	
	*4-056-265-11	LABEL, INFORMATION		34	1-452-032-00	MAGNET, DISC ; 10mm φ	
		[AUS for USA-made set]		35	1-452-094-00	MAGNET, ROTATABLE DISK ; 15mm φ	
11	*8-933-199-00	A BOARD, COMPLETE		36	X-4030-584-1	PERMALLOY ASSY, CORRECTION	
12	1-452-369-41	MAGNET, RING (6P)		37	*4-045-471-01	LABEL, ENERGY STAR	
13	4-046-898-01	SPACER, MG		38	4-382-854-01	SCREW (M3X8), P, SW(+)	
14	X-4033-948-1	HOLDER ASSY, PWB	15				
15	4-041-627-01	SCREW (M4X20), HEXAGON HEAD					

Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.


6-1-2. CHASSIS (CPD-200SFT)

- 7-685-648-79 +BVTP 3X12
- ▲ 7-685-646-79 +BVTP 3X8
- 7-685-663-71 +BVTP 4X16
- 7-682-548-04 +BVTT 3X8
- Δ 7-682-562-04 +BVTT 4X10
- ∇ 7-685-650-79 +BVTP 3X16
- \diamond 7-685-659-71 +BVTP 4X8



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
51	X-4033-961-1	BEZEL ASSY [for Japan-made set]	52,53	71	*4-045-130-01	BRACKET, CABLE [for Japan-made set]	
	X-4034-057-1	BEZEL ASSY [for UK-made set]	52,53		*4-045-130-21	BRACKET, CABLE [for UK-made set]	
52	4-046-410-21	BUTTON, POWER [for Japan-made set]		72	*4-045-131-01	STOPPER, CABLE [for Japan-made set]	
	4-046-410-31	BUTTON, POWER [for UK-made set]			*4-045-131-11	STOPPER, CABLE [for UK-made set]	
53	3-571-801-01	SPRING, COMPRESSION		73	1-776-975-31	CABEL ASSY (15P DSUB CONNECTOR)	
54	4-046-427-01	CABINET		74	X-4032-232-1	STAND ASSY, SWIVEL	75-80
55	4-046-903-01	COVER, SCREW [for Japan-made set]		75	4-046-901-01	SPRING, TENSION [for Japan-made set]	
	4-046-903-11	COVER, SCREW [for UK-made set]			4-052-618-01	SPRING, EXTENSION [for UK-made set]	
56	Δ 8-738-605-95	ITC ASSY (17SAFK-R6) (AEP, UK)	57-59	76	*4-043-646-01	HOLDER, STAND	
57	Δ 8-738-605-05	PICTURE TUBE (17SAFK) (AEP, UK)		77	4-041-623-01	STOPPER (A)	
58	Δ 8-451-478-71	DEFLECTION YOKE Y (17SAH5-M7)		78	4-046-426-01	COVER, BOTTOM	
59	4-050-492-01	SPACER,DY		79	*4-041-625-01	RING, TILT SWIVEL	
60	*3-704-372-01	HOLDER, HV CABEL		80	4-041-621-01	STOPPER (B) [for UK-made set]	
61	*8-933-199-00	A BOARD, COMPLETE		81	4-056-713-01	HOLDER, SIDE	
62	1-452-369-41	MAGNET, RING (6P)		82	*4-056-180-01	LABEL, INFORMATION	[for Japan-made set]
63	4-046-898-01	SPACER, MG			*4-056-245-01	LABEL, INFORMATION [for UK-made set]	
64	X-4033-948-1	HOLDER ASSY, PWB	65	83	4-308-870-00	CLIP, LEAD WIRE	
65	4-041-627-01	SCREW (M4X20), HEXAGON HEAD		84	1-452-032-00	MAGNET, DISC ; 10mm ϕ	
66	*4-047-316-01	SPRING, TENSION		85	1-452-094-00	MAGNET, ROTABLE DISK;15mm ϕ	
67	Δ 1-409-975-12	COIL, DEMAGNETIZATION		86	X-4030-584-1	PERMALLOY ASSY, CORRECTION	
68	4-365-808-01	SCREW (5), TAPPING		87	7-382-854-01	SCREW (M3X8), P, SW(+)	
69	*8-933-208-00	D BOARD, COMPLETE					
70	Δ X-4034-327-1	TRANSFORMER ASSY, FLYBACK	(NX-4111//J1E4)				

6-2. PACKING MATERIALS



The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
101	Δ 1-558-481-12	CORD, POWER (10A/125V) (CPD-200SF AUS)		104	* 4-046-461-01	CUSHION (UPPER) (ASSY)	
	Δ 1-765-717-11	CORD SET, POWER (10A/250V) (CPD-200SF ES/CPD-200SFT AEP)		105	* 4-041-927-01	BAG, POLYETHYLENE [CPD-200SFT for UK-made set]	
	Δ 1-765-718-11	CORD SET, POWER (10A/125V) (CPD-200SF U/C)			* 4-041-927-11	BAG, POLYETHYLENE [except CPD-200SFT for UK-made set]	
	Δ 1-775-706-11	CORD SET, POWER (10A/250V) (CPD-200SFT UK)		106	* 4-046-460-01	PAT, TILT FIXED	
102	1-774-648-21	ADAPTOR (for VGA) (CPD-200SF ES, AUS/CPD-200SFT)		107	* 4-046-462-01	CUSHION (LOWER) (ASSY)	
	1-573-983-31	ADAPTOR (for MAC) (CPD-200SF)		108	* 4-055-191-01	INDIVIDUAL CARTON [CPD-200SF for Japan-made set]	
103	3-858-024-11	MANUAL, INSTRUCTION [CPD-200SF for USA-made set]			* 4-055-899-01	INDIVIDUAL CARTON [CPD-200SFT for Japan-made set]	
	3-858-024-21	MANUAL, INSTRUCTION [CPD-200SFT for UK-made set]			* 4-056-175-01	INDIVIDUAL CARTON [CPD-200SF for USA-made set]	
	3-858-024-41	MANUAL, INSTRUCTION [CPD-200SFT for Japan-made set]			* 4-056-176-01	INDIVIDUAL CARTON [CPD-200SFT for UK-made set]	
	3-858-024-31	MANUAL, INSTRUCTION [CPD-200SF for Japan-made set]		109	4-056-722-01	Windows 95 Monitor Information Disk	



SECTION 7 ELECTRICAL PARTS LIST

NOTE:

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par un trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

The components identified by \square in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

RESISTORS

- All resistors are in ohms
- F : nonflammable
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

CAPACITORS

MF: μ F

COILS

UH: μ H

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
	* 8-933-199-00	A BOARD, COMPLETE					
	4-382-854-01	SCREW (M3X8), P, SW (+)					
		<CAPACITOR>					
C001	1-163-125-00	CERAMIC CHIP 220pF	5% 50V	C055	1-163-231-11	CERAMIC CHIP 15pF	5% 50V
C002	1-104-653-11	ELECT 220MF	20% 16V	C088	1-126-933-11	ELECT 100MF	20% 16V
C003	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C092	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C004	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C100	1-126-967-11	ELECT 47MF	20% 16V
C005	1-163-243-11	CERAMIC CHIP 47pF	5% 50V				
C006	1-163-243-11	CERAMIC CHIP 47pF	5% 50V	C101	1-126-157-11	ELECT 10MF	20% 16V
C007	1-124-589-11	ELECT 47MF	20% 16V	C102	1-163-087-00	CERAMIC CHIP 4pF	0.25pF 50V
C008	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C103	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C009	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C104	1-107-823-11	CERAMIC CHIP 0.47MF	10% 16V
C010	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C105	1-124-903-11	ELECT 1MF	20% 50V
C011	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C106	1-117-450-11	CAPACITOR 0.047MF	10% 250V
C012	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C107	1-163-125-00	CERAMIC CHIP 220pF	5% 50V
C013	1-164-161-11	CERAMIC CHIP 0.0022MF	10% 50V	C108	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C014	1-128-562-11	ELECT 47MF	20% 100V	C201	1-126-157-11	ELECT 10MF	20% 16V
C015	1-106-220-00	MYLAR 0.1MF	10% 100V	C202	1-163-087-00	CERAMIC CHIP 4pF	0.25pF 50V
C016	1-126-933-11	ELECT 100MF	20% 16V	C203	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C017	1-126-967-11	ELECT 47MF	20% 16V	C204	1-107-823-11	CERAMIC CHIP 0.47MF	10% 16V
C018	1-107-961-91	ELECT 10MF	20% 250V	C205	1-124-903-11	ELECT 1MF	20% 50V
C019	1-163-243-11	CERAMIC CHIP 47pF	5% 50V	C206	1-117-450-11	CAPACITOR 0.047MF	10% 250V
C020	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C207	1-163-125-00	CERAMIC CHIP 220pF	5% 50V
C022	1-126-933-11	ELECT 100MF	20% 16V	C208	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C027	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C209	1-162-117-00	CERAMIC 100pF	10% 500V
C028	1-126-933-11	ELECT 100MF	20% 16V	C301	1-126-157-11	ELECT 10MF	20% 16V
C029	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C302	1-163-087-00	CERAMIC CHIP 4pF	0.25pF 50V
C031	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V	C303	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C032	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C304	1-107-823-11	CERAMIC CHIP 0.47MF	10% 16V
C033	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C305	1-124-903-11	ELECT 1MF	20% 50V
C034	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V	C306	1-117-450-11	CAPACITOR 0.047MF	10% 250V
C035	1-162-134-11	CERAMIC 470pF	10% 2KV	C307	1-163-125-00	CERAMIC CHIP 220pF	5% 50V
C036	1-163-231-11	CERAMIC CHIP 15pF	5% 50V	C308	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C037	1-106-367-00	MYLAR 0.01MF	10% 100V	C309	1-162-117-00	CERAMIC 100pF	10% 500V
C038	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C330	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C039	1-126-933-11	ELECT 100MF	20% 16V	C334	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C040	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C351	1-137-528-11	FILM 0.1MF	10% 250V
C041	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V				
C042	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V				
						<CONNECTOR>	
				CN301*	1-506-108-41	PIN, CONNECTOR (TERMINAL PIN)	
				CN302	1-695-915-11	TAB (CONTACT)	
				CN303	1-695-915-11	TAB (CONTACT)	
				CN305*	1-564-525-11	PLUG, CONNECTOR	10P
				CN306*	1-564-526-11	PLUG, CONNECTOR	11P
				CN307*	1-564-512-11	PLUG, CONNECTOR	9P
				CN308*	1-564-507-11	PLUG, CONNECTOR	4P



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
R028	1-216-372-11	METAL OXIDE 1.8	5% 2W F	R211	1-260-094-11	CARBON 390	5% 1/2W
R029	1-216-097-91	METAL GLAZE 100K	5% 1/10W	R212	1-216-061-00	METAL GLAZE 3.3K	5% 1/10W
R030	1-216-097-91	METAL GLAZE 100K	5% 1/10W				
R032	1-216-657-11	METAL CHIP 1.8K	0.50%1/10W	R213	1-216-009-00	METAL GLAZE 22	5% 1/10W
R033	1-216-667-11	METAL CHIP 4.7K	0.50%1/10W	R214	1-216-121-91	METAL GLAZE 1M	5% 1/10W
R034	1-216-049-91	METAL GLAZE 1K	5% 1/10W	R216	1-216-065-00	METAL GLAZE 4.7K	5% 1/10W
R035	1-216-119-00	METAL GLAZE 820K	5% 1/10W	R217	1-249-397-11	CARBON 22	5% 1/4W F
R036	1-216-109-00	METAL GLAZE 330K	5% 1/10W	R250	1-216-295-91	CONDUCTOR, CHIP	
R037	1-216-119-00	METAL GLAZE 820K	5% 1/10W	R251	1-202-549-00	SOLID 100	20% 1/2W
R038	1-216-099-00	METAL GLAZE 120K	5% 1/10W	R262	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R039	1-216-111-91	METAL GLAZE 390K	5% 1/10W	R301	1-216-631-11	METAL CHIP 150	0.50%1/10W
R040	1-216-119-00	METAL GLAZE 820K	5% 1/10W	R302	1-216-631-11	METAL CHIP 150	0.50%1/10W
R041	1-216-685-11	METAL CHIP 27K	0.50%1/10W	R303	1-216-097-91	METAL GLAZE 100K	5% 1/10W
R042	1-216-295-91	CONDUCTOR, CHIP		R304	1-216-025-91	METAL GLAZE 100	5% 1/10W
R044	1-216-061-00	METAL GLAZE 3.3K	5% 1/10W	R305	1-216-659-11	METAL CHIP 2.2K	0.50%1/10W
R045	1-216-061-00	METAL GLAZE 3.3K	5% 1/10W	R306	1-216-065-00	METAL GLAZE 4.7K	5% 1/10W
R048	1-211-885-21	METAL 2.2M	5% 1W	R307	1-216-073-00	METAL GLAZE 10K	5% 1/10W
R049	1-216-095-00	METAL GLAZE 82K	5% 1/10W	R308	1-216-699-11	METAL CHIP 100K	0.50%1/10W
R053	1-211-895-11	METAL 10M	10% 1/4W	R309	1-216-121-91	METAL GLAZE 1M	5% 1/10W
R054	1-216-017-91	METAL GLAZE 47	5% 1/10W	R310	1-216-697-91	METAL CHIP 82K	0.50%1/10W
R055	1-216-017-91	METAL GLAZE 47	5% 1/10W	R311	1-260-094-11	CARBON 390	5% 1/2W
R056	1-216-041-00	METAL GLAZE 470	5% 1/10W	R312	1-216-061-00	METAL GLAZE 3.3K	5% 1/10W
R057	1-216-025-91	METAL GLAZE 100	5% 1/10W	R313	1-216-009-00	METAL GLAZE 22	5% 1/10W
R058	1-216-659-11	METAL CHIP 2.2K	0.50%1/10W	R314	1-216-121-91	METAL GLAZE 1M	5% 1/10W
R059	1-216-119-00	METAL GLAZE 820K	5% 1/10W	R316	1-216-065-00	METAL GLAZE 4.7K	5% 1/10W
R064	1-202-830-00	SOLID 10K	20% 1/2W	R317	1-249-397-11	CARBON 22	5% 1/4W F
R077	1-216-049-91	METAL GLAZE 1K	5% 1/10W	R350	1-216-295-91	CONDUCTOR, CHIP	
R101	1-216-631-11	METAL CHIP 150	0.50%1/10W	R351	1-202-549-00	SOLID 100	20% 1/2W
R102	1-216-631-11	METAL CHIP 150	0.50%1/10W	R362	1-216-049-91	METAL GLAZE 1K	5% 1/10W
R103	1-208-806-11	METAL CHIP 10K	0.50%1/10W				
R104	1-216-025-91	METAL GLAZE 100	5% 1/10W			<VARIABLE RESISTOR>	
R105	1-216-659-11	METAL CHIP 2.2K	0.50%1/10W	RV001	1-223-410-11	RES, ADJ, METAL FILM	110M (H.STAT)
R106	1-216-065-00	METAL GLAZE 4.7K	5% 1/10W				
R107	1-216-073-00	METAL GLAZE 10K	5% 1/10W			<SPARK GAP>	
R108	1-216-699-11	METAL CHIP 100K	0.50%1/10W	SG001	1-519-422-11	GAP, SPARK	
R109	1-216-121-91	METAL GLAZE 1M	5% 1/10W	SG101	1-519-504-11	GAP, DISCHARGE	
R110	1-216-697-91	METAL CHIP 82K	0.50%1/10W	SG201	1-519-504-11	GAP, DISCHARGE	
R111	1-260-094-11	CARBON 390	5% 1/2W	SG301	1-519-504-11	GAP, DISCHARGE	
R112	1-216-061-00	METAL GLAZE 3.3K	5% 1/10W			<CRYSTAL>	
R113	1-216-009-00	METAL GLAZE 22	5% 1/10W	X1	1-567-890-11	VIBRATOR, CRYSTAL	
R114	1-216-121-91	METAL GLAZE 1M	5% 1/10W				
R116	1-216-065-00	METAL GLAZE 4.7K	5% 1/10W				
R117	1-249-397-11	CARBON 22	5% 1/4W F				
R150	1-216-295-91	CONDUCTOR, CHIP					
R151	1-202-549-00	SOLID 100	20% 1/2W				
R162	1-216-049-91	METAL GLAZE 1K	5% 1/10W				
R201	1-216-631-11	METAL CHIP 150	0.50%1/10W				
R202	1-216-631-11	METAL CHIP 150	0.50%1/10W				
R203	1-216-097-91	METAL GLAZE 100K	5% 1/10W				
R204	1-216-025-91	METAL GLAZE 100	5% 1/10W				
R205	1-216-659-11	METAL CHIP 2.2K	0.50%1/10W				
R206	1-216-065-00	METAL GLAZE 4.7K	5% 1/10W				
R207	1-216-073-00	METAL GLAZE 10K	5% 1/10W				
R208	1-216-699-11	METAL CHIP 100K	0.50%1/10W				
R209	1-216-121-91	METAL GLAZE 1M	5% 1/10W				
R210	1-216-697-91	METAL CHIP 82K	0.50%1/10W				

* 8-933-208-00 D BOARD, COMPLTE

3-710-578-01 COVER, VOLUME, 6 MOLD
* 4-043-990-01 HEAT SINK (D601)
4-045-132-01 HOLDER (A), LED (D911)
4-050-691-01 HOLDER, IC (IC505)
4-051-602-01 SHEET, RADIATION (Q653)

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par un trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
	4-051-627-01	SHEET, INSULATING (IC505)		C553	1-163-038-91	CERAMIC CHIP 0.1MF	25V
	4-056-129-01	HOLDER, IC (IC601)		C554	1-137-399-11	FILM 0.1MF	5% 50V
	4-389-025-01	SCREW (M4) (EXT TOOTH WASHER)		C558	1-102-002-00	CERAMIC 680pF	10% 500V
	7-685-647-79	SCREW +BVTP 3X10 TYPE2		C560	1-137-375-11	FILM 0.068MF	5% 50V
				C561	1-124-903-11	ELECT 1MF	20% 50V
		<CAPACITOR>		C562	1-126-964-11	ELECT 10MF	20% 50V
C401	1-128-528-11	ELECT 470MF	20% 25V	C563	1-126-964-11	ELECT 10MF	20% 50V
C402	1-102-112-00	CERAMIC 330pF	10% 50V	C564	1-106-375-12	MYLAR 0.022MF	200V
C403	1-137-399-11	FILM 0.1MF	5% 50V	C566	1-126-964-11	ELECT 10MF	20% 50V
C404	1-106-228-00	MYLAR 0.22MF	10% 100V	C569	1-137-370-11	FILM 0.01MF	5% 50V
C405	1-107-894-11	ELECT 220MF	20% 35V	C570	1-137-370-11	FILM 0.01MF	5% 50V
C406	1-126-105-11	ELECT 1000MF	20% 25V	C571	1-137-370-11	FILM 0.01MF	5% 50V
C407	1-101-006-00	CERAMIC 0.047MF	50V	C572	1-163-038-91	CERAMIC CHIP 0.1MF	25V
C408	1-136-105-00	FILM 0.33MF	5% 200V	C573	1-137-372-11	FILM 0.022MF	5% 50V
C410	1-108-377-91	FILM 0.01MF	10% 100V	C574	1-137-368-11	FILM 0.0047MF	5% 50V
C501	1-117-413-11	CAPACITOR 0.006MF	3% 1.8KV	C575	1-128-528-11	ELECT 470MF	20% 25V
C502	1-107-961-91	ELECT 10MF	20% 250V	C576	1-107-714-11	ELECT 10MF	20% 16V
C503	1-107-649-11	ELECT 2.2MF	20% 250V	C578	1-117-411-11	CAPACITOR 0.16MF	5% 250V
C504	1-162-815-11	CERAMIC 47pF	5% 500V	C579	1-117-412-11	CAPACITOR 0.24MF	5% 250V
C505	1-136-173-00	FILM 0.47MF	5% 50V	C580	1-137-370-11	FILM 0.01MF	5% 50V
C506	1-113-714-11	FILM 2000pF	3% 2KV	C581	1-136-173-00	FILM 0.47MF	5% 50V
C507	1-102-157-00	CERAMIC 560pF	10% 500V	C582	1-137-399-11	FILM 0.1MF	5% 50V
C508	1-104-664-11	ELECT 47MF	20% 25V	C584	1-137-370-11	FILM 0.01MF	5% 50V
C509	1-137-368-11	FILM 0.0047MF	5% 50V	C601 Δ	1-113-900-51	CERAMIC 470pF	10% 250V
C511	1-136-244-11	FILM 0.1MF	5% 50V	C602 Δ	1-113-912-51	CERAMIC 0.0047MF	20% 250V
C512	1-137-370-11	FILM 0.01MF	5% 50V	C603 Δ	1-104-708-51	FILM 0.47MF	20% 250V
C513	1-126-964-11	ELECT 10MF	20% 50V	C604 Δ	1-104-708-51	FILM 0.47MF	20% 250V
C515	1-115-509-11	FILM 0.068MF	5% 250V	C605 Δ	1-113-912-51	CERAMIC 0.0047MF	20% 250V
C516	1-115-512-11	FILM 0.15MF	5% 250	C606 Δ	1-113-900-51	CERAMIC 470pF	10% 250V
C517	1-117-451-81	CAPACITOR 0.43MF	5% 250V	C607	1-126-968-11	ELECT 100MF	20% 50V
C518	1-115-524-11	FILM 1.5MF	5% 250V	C608	1-113-912-11	CERAMIC 0.0047MF	20% 250V
C519	1-137-370-11	FILM 0.01MF	5% 50V	C611	1-104-666-11	ELECT 220MF	20% 25V
C522	1-102-030-00	CERAMIC 330pF	10% 500V	C612	1-126-971-11	ELECT 470MF	20% 50V
C523	1-109-879-11	CERAMIC 22pF	5% 2KV	C613	1-102-074-00	CERAMIC 0.001MF	10% 50V
C524	1-136-749-11	FILM 0.36MF	5% 400V	C617	1-126-925-11	ELECT 470MF	20% 10V
C525	1-136-105-00	FILM 0.33MF	5% 200V	C619	1-136-619-11	FILM 0.0016MF	3% 2KV
C526	1-106-375-12	MYLAR 0.022MF	200V	C643	1-113-912-11	CERAMIC 0.0047MF	20% 250V
C529	1-115-349-51	CERAMIC 0.01MF	2KV	C652	1-125-700-11	ELECT 220MF	20% 200V
C530	1-137-368-11	FILM 0.0047MF	5% 50V	C653	1-107-936-11	ELECT 470MF	20% 100V
C531	1-137-399-11	FILM 0.1MF	5% 50V	C654	1-107-899-11	ELECT 3300MF	20% 35V
C532	1-137-370-11	FILM 0.01MF	5% 50V	C655	1-107-899-11	ELECT 3300MF	20% 35V
C533	1-136-177-00	FILM 1MF	5% 50V	C656	1-126-105-11	ELECT 1000MF	20% 25V
C535	1-137-399-11	FILM 0.1MF	5% 50V	C657	1-107-956-11	ELECT 220MF	20% 200V
C536	1-126-965-11	ELECT 22MF	20% 50V	C658	1-107-896-11	ELECT 470MF	20% 35V
C537	1-124-903-11	ELECT 1.0MF	20% 50V	C659	1-128-526-11	ELECT 100MF	20% 25V
C538	1-136-203-11	FILM 0.01MF	5% 630V	C661	1-126-971-11	ELECT 470MF	20% 50V
C543	1-102-106-00	CERAMIC 100pF	10% 50V	C662	1-126-943-11	ELECT 2200MF	20% 25V
C544	1-137-366-11	FILM 0.0022MF	5% 50V	C663	1-128-526-11	ELECT 100MF	20% 25V
C545	1-137-366-11	FILM 0.0022MF	5% 50V	C701	1-137-370-11	FILM 0.01MF	5% 50V
C546	1-137-366-11	FILM 0.0022MF	5% 50V	C702	1-126-935-11	ELECT 470MF	20% 16V
C547	1-163-005-11	CERAMIC CHIP 470pF	10% 50V	C703	1-163-038-91	CERAMIC CHIP 0.1MF	25V
C548	1-137-368-11	FILM 0.0047MF	5% 50V	C704	1-126-935-11	ELECT 470MF	20% 16V
C549	1-117-411-11	CAPACITOR 0.16MF	5% 250V	C705	1-163-038-91	CERAMIC CHIP 0.1MF	25V
C550	1-137-364-11	FILM 0.001MF	5% 50V	C706	1-124-925-11	ELECT 2.2MF	20% 50V
C551	1-163-251-11	CERAMIC CHIP 100pF	5% 50V	C707	1-137-372-11	FILM 0.022MF	5% 50V
C552	1-126-952-11	ELECT 1000MF	20% 16V	C708	1-163-243-11	CERAMIC CHIP 47pF	5% 50V



Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
C709	1-124-903-11	ELECT	1MF 20% 50V	<CONNECTOR>			
C710	1-137-399-11	FILM	0.1MF 5% 50V	CN401*	1-580-837-11	PIN, CONNECTOR (PC BOARD)	3P
C711	1-137-399-11	FILM	0.1MF 5% 50V	CN501*	1-778-903-11	PIN, CONNECTOR (PC BOARD)	6P
C712	1-136-495-11	FILM	0.068MF 5% 50V	CN503	1-695-915-11	TAB (CONTACT)	
C714	1-137-399-11	FILM	0.1MF 5% 50V	CN600 Δ	1-251-444-11	INLET, AC	
C715	1-137-366-11	FILM	0.0022MF 5% 50V	CN601*	1-564-513-11	PLUG, CONNECTOR	10P
C716	1-124-768-11	ELECT	4.7MF 20% 35V	CN603*	1-506-371-00	PIN, CONNECTOR	2P
C717	1-136-169-00	FILM	0.22MF 5% 50V	CN605	1-691-960-11	PIN, CONNECTOR (PC BOARD)	3P
C718	1-136-169-00	FILM	0.22MF 5% 50V	CN901*	1-508-879-11	BASE POST	
C719	1-163-038-91	CERAMIC CHIP	0.1MF 25V	CN902*	1-564-514-11	PLUG, CONNECTOR	11P
C720	1-137-399-11	FILM	0.1MF 5% 50V	CN903*	1-564-509-11	PLUG, CONNECTOR	6P
C721	1-126-935-11	ELECT	470MF 20% 16V	<DIODE>			
C722	1-137-370-11	FILM	0.01MF 5% 50V	D402	8-719-979-58	DIODE EGP10D	
C723	1-102-112-00	CERAMIC	330pF 10% 50V	D403	8-719-911-19	DIODE 1SS119-25	
C724	1-136-173-00	FILM	0.47MF 5% 50V	D404	8-719-908-03	DIODE GP08D	
C725	1-136-173-00	FILM	0.47MF 5% 50V	D405	8-719-908-03	DIODE GP08D	
C728	1-124-768-11	ELECT	4.7MF 20% 35V	D501	8-719-975-77	DIODE SB340	
C729	1-126-963-11	ELECT	4.7MF 20% 50V	D502	8-719-049-12	DIODE 5TUZ52	
C730	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	4-382-854-01 SCREW (M3X8), P, SW (+) ; D502			
C731	1-163-006-11	CERAMIC CHIP	560pF 10% 50V	D503	8-719-911-19	DIODE 1SS119-25	
C732	1-126-935-11	ELECT	470MF 20% 16V	D505	8-719-110-31	ZENER DIODE RD12ESB2	
C803	1-126-965-11	ELECT	22MF 20% 50V	D506	8-719-939-79	DIODE GMA01-BT	
C804	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	D507	8-719-939-79	DIODE GMA01-BT	
C806	1-126-964-11	ELECT	10MF 20% 50V	D512	8-719-110-31	ZENER DIODE RD12ESB2	
C807	1-104-663-11	ELECT	33MF 20% 25V	D513	8-719-018-82	DIODE RGP02-20EL-6394	
C808	1-104-663-11	ELECT	33MF 20% 25V	D516	8-719-051-97	DIODE 3DL41A(LC6-15)	
C809	1-163-038-91	CERAMIC CHIP	0.1MF 25V	D517	8-719-911-19	DIODE 1SS119-25	
C901	1-163-038-91	CERAMIC CHIP	0.1MF 25V	D518	8-719-947-06	DIODE RGP10JPKG23	
C902	1-163-038-91	CERAMIC CHIP	0.1MF 25V	D524	8-719-970-83	DIODE HSS82	
C903	1-102-112-00	CERAMIC	330pF 10% 50V	D525	8-719-110-31	ZENER DIODE RD12ESB2	
C904	1-163-038-91	CERAMIC CHIP	0.1MF 25V	D526	8-719-051-97	DIODE 3DL41A(LC6-15)	
C908	1-163-038-91	CERAMIC CHIP	0.1MF 25V	D527	8-719-110-31	ZENER DIODE RD12ESB2	
C909	1-124-925-11	ELECT	2.2MF 20% 50V	D528	8-719-941-74	DIODE ERB91-02	
C910	1-124-925-11	ELECT	2.2MF 20% 50V	D529	8-719-911-19	DIODE 1SS119-25	
C911	1-124-925-11	ELECT	2.2MF 20% 50V	D530	8-719-109-85	ZENER DIODE RD5.1ESB2	
C912	1-124-925-11	ELECT	2.2MF 20% 50V	D601 Δ	8-719-025-88	DIODE GBU4JL-6088	
C913	1-124-925-11	ELECT	2.2MF 20% 50V	4-382-854-01 SCREW (M3X8), P, SW (+) ; D601			
C914	1-124-925-11	ELECT	2.2MF 20% 50V	D604	8-719-110-02	ZENER DIODE RD7.5ESB1	
C915	1-163-038-91	CERAMIC CHIP	0.1MF 25V	D606	8-719-302-43	DIODE EL1Z	
C916	1-163-038-91	CERAMIC CHIP	0.1MF 25V	D607	8-719-302-43	DIODE EL1Z	
C917	1-163-038-91	CERAMIC CHIP	0.1MF 25V	D608	8-719-300-76	DIODE RH-1A	
C918	1-124-903-11	ELECT	1MF 20% 50V	D609	8-719-300-76	DIODE RH-1A	
C919	1-163-231-11	CERAMIC CHIP	15pF 5% 50V	D612	8-719-970-83	DIODE HSS82	
C920	1-163-231-11	CERAMIC CHIP	15pF 5% 50V	D650	8-719-048-62	DIODE UF3ML-6505	
C921	1-163-038-91	CERAMIC CHIP	0.1MF 25V	D651	8-719-979-58	DIODE EGP10D	
C922	1-126-952-11	ELECT	1000MF 20% 16V	D652	8-719-048-63	DIODE UG4DL-6506	
C923	1-126-963-11	ELECT	4.7MF 20% 50V	D653	8-719-048-63	DIODE UG4DL-6506	
C924	1-163-038-91	CERAMIC CHIP	0.1MF 25V	D654	8-719-051-97	DIODE 3DL41A(LC6-15)	
C925	1-137-370-11	FILM	0.01MF 5% 50V	D655	8-719-911-19	DIODE 1SS119-25	
C926	1-163-005-11	CERAMIC CHIP	470pF 10% 50V	D657	8-719-048-61	DIODE EGP20DL-6349	
C927	1-163-005-11	CERAMIC CHIP	470pF 10% 50V	D658	8-719-048-61	DIODE EGP20DL-6349	
C928	1-124-903-11	ELECT	1MF 20% 50V	D659	8-719-110-17	ZENER DIODE RD10ESB2	
C930	1-163-239-11	CERAMIC CHIP	33pF 5% 50V	D660	8-719-911-19	DIODE 1SS119-25	
C931	1-126-965-11	ELECT	22MF 20% 50V	D701	8-719-911-19	DIODE 1SS119-25	



Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
L507	1-412-537-31	INDUCTOR 100UH		<RESISTOR>			
L508	1-411-594-11	COIL, CHOKE 5mH		R401	1-208-806-11	METAL CHIP 10K	0.50%1/10W
L509	1-411-585-11	COIL, HORIZONTAL LINEARITY		R402	1-215-441-00	METAL 6.8K	1% 1/4W
L511	1-429-301-11	TRANSFORMER, FERRITE (HCT)		R405	1-249-383-11	CARBON 1.5	5% 1/4W F
L512	1-411-567-11	COIL, CHOKE 500UH		R406	1-249-421-11	CARBON 2.2K	5% 1/4W
L513	1-459-075-11	COIL,DYNAMIC CONVERSION CHOKE		R407	1-215-866-11	METAL OXIDE 330	5% 1W F
L651	1-406-665-11	COIL, CHOKE 100UH		R408	1-214-798-21	METAL 1.8	1% 1/2W
L652	1-406-665-11	COIL, CHOKE 100UH		R409	1-249-421-11	CARBON 2.2K	5% 1/4W
L653	1-412-537-31	INDUCTOR 100UH		R410	1-215-441-00	METAL 6.8K	1% 1/4W
L701	1-412-537-31	INDUCTOR 100UH		R411	1-215-445-00	METAL 10K	1% 1/4W
<FILTER>				R412	1-216-295-91	CONDUCTOR, CHIP	
LF601	1-426-789-11	TRANSFORMER, LINE FILTER (LFT)		R413	1-216-295-91	CONDUCTOR, CHIP	
<TRANSISTOR>				R416	1-249-413-11	CARBON 470	5% 1/4W F
Q501	8-729-119-76	TRANSISTOR 2SA1175-HFE		R417	1-214-798-21	METAL 1.8	1% 1/2W
Q502	8-729-032-61	TRANSISTOR 2SC5022-02		R418	1-215-473-00	METAL 150K	1% 1/4W
Q503	8-729-820-73	TRANSISTOR 2SC3746		R419	1-215-473-00	METAL 150K	1% 1/4W
Q505	8-729-015-28	TRANSISTOR IRFI9630GS		R500	1-247-891-00	CARBON 330K	5% 1/4W
		4-382-854-01 SCREW (M3X8), P, SW (+) ; Q505		R502	1-216-395-00	METAL OXIDE 3.3	5% 3W F
Q507	8-729-039-92	TRANSISTOR 2SC5380		R503	1-216-395-00	METAL OXIDE 3.3	5% 3W F
		4-382-854-01 SCREW (M3X8), P, W (+) ; Q507		R504	1-249-385-11	CARBON 2.2	5% 1/4W F
Q510	8-729-032-88	TRANSISTOR IRFPG50LF21		R505	1-249-401-11	CARBON 47	5% 1/4W
		4-382-854-01 SCREW (M3X8), P, SW (+) ; Q510		R506	1-247-807-31	CARBON 100	5% 1/4W
Q511	8-729-027-14	TRANSISTOR 2SK1904		R507	1-249-421-11	CARBON 2.2K	5% 1/4W
Q512	8-729-027-14	TRANSISTOR 2SK1904		R508	1-215-861-00	METAL OXIDE 47	5% 1W F
Q513	8-729-021-79	TRANSISTOR 2SK1307		R509	1-247-863-91	CARBON 22K	5% 1/4W
Q515	8-729-119-78	TRANSISTOR 2SC2785-HFE		R510	1-216-449-11	METAL OXIDE 56	5% 2W F
Q516	8-729-119-76	TRANSISTOR 2SA1175-HFE		R511	1-249-397-11	CARBON 22	5% 1/4W F
Q518	8-729-927-09	TRANSISTOR IRFI9630		R512	1-216-049-91	METAL GLAZE 1K	5% 1/10W
Q519	8-729-119-78	TRANSISTOR 2SC2785-HFE		R513	1-215-910-00	METAL OXIDE 68	5% 3W F
Q520	8-729-119-76	TRANSISTOR 2SA1175-HFE		R514	1-249-441-11	CARBON 100K	5% 1/4W
Q522	8-729-119-78	TRANSISTOR 2SC2785-HFE		R515	1-247-887-00	CARBON 220K	5% 1/4W
Q523	8-729-119-76	TRANSISTOR 2SA1175-HFE		R516	1-249-429-11	CARBON 10K	5% 1/4W
Q524	8-729-119-78	TRANSISTOR 2SC2785-HFE		R517	1-215-477-00	METAL 220K	1% 1/4W
Q525	8-729-021-79	TRANSISTOR 2SK1307		R518	1-216-071-00	METAL GLAZE 8.2K	5% 1/10W
Q526	8-729-140-50	TRANSISTOR 2SC3209LK		R519	1-218-762-11	METAL CHIP 270K	0.50%1/10W
Q604	8-729-028-34	TRANSISTOR 2SD1640Q,R		R520	1-249-437-11	CARBON 47K	5% 1/4W
Q605	8-729-326-11	TRANSISTOR 2SC2611		R521	1-249-437-11	CARBON 47K	5% 1/4W
Q651	8-729-141-83	TRANSISTOR 2SB1094-LK		R522	1-249-437-11	CARBON 47K	5% 1/4W
Q652	8-729-119-78	TRANSISTOR 2SC2785-HFE		R523	1-249-437-11	CARBON 47K	5% 1/4W
Q653	8-729-142-46	TRANSISTOR 2SC2001-LK		R524	1-249-417-11	CARBON 1K	5% 1/4W F
Q655	8-729-029-86	TRANSISTOR DTC124ESA		R525	1-249-417-11	CARBON 1K	5% 1/4W F
Q656	8-729-027-52	TRANSISTOR DTC124EKA-T146		R526	1-249-417-11	CARBON 1K	5% 1/4W F
Q657	8-729-027-52	TRANSISTOR DTC124EKA-T146		R528	1-249-429-11	CARBON 10K	5% 1/4W
Q658	8-729-140-96	TRANSISTOR 2SD774-34		R529	1-215-421-00	METAL 1K	1% 1/4W
Q703	8-729-422-27	TRANSISTOR 2SD601A-Q		R531	1-249-429-11	CARBON 10K	5% 1/4W
Q704	8-729-216-22	TRANSISTOR 2SA1162-G		R532	1-249-397-11	CARBON 22	5% 1/4W F
Q801	8-729-422-27	TRANSISTOR 2SD601A-Q		R533	1-215-913-11	METAL OXIDE 220	5% 3W F
Q802	8-729-422-27	TRANSISTOR 2SD601A-Q		R534	1-215-913-11	METAL OXIDE 220	5% 3W F
Q901	8-729-216-22	TRANSISTOR 2SA1162-G		R535	1-215-476-91	METAL 180K	1% 1/4W
Q902	8-729-027-52	TRANSISTOR DTC124EKA-T146		R536	1-215-421-00	METAL 1K	1% 1/4W
				R537	1-249-417-11	CARBON 1K	5% 1/4W
				R538	1-247-895-91	CARBON 470K	5% 1/4W
				R539	1-215-431-00	METAL 2.7K	1% 1/4W
				R540	1-215-471-00	METAL 120K	1% 1/4W
				R541	1-215-431-00	METAL 2.7K	1% 1/4W
				R542	1-215-469-00	METAL 100K	1% 1/4W

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par un trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
R543	1-249-389-11	CARBON	4.7	5%	1/4W	F	
R544	1-216-690-11	METAL CHIP	43K	0.50%	1/10W		
R545	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W		
R546	1-249-427-11	CARBON	6.8K	5%	1/4W	F	
R547	1-215-923-00	METAL OXIDE	10K	5%	3W	F	
R548	1-249-417-11	CARBON	1K	5%	1/4W	F	
R549	1-215-905-11	METAL OXIDE	10	5%	3W	F	
R550	1-215-905-11	METAL OXIDE	10	5%	3W	F	
R551	1-215-926-00	METAL OXIDE	33K	5%	3W	F	
R552	1-247-863-91	CARBON	22K	5%	1/4W		
R553	1-260-296-11	CARBON	2.2	5%	1/2W		
R554	1-215-473-00	METAL	150K	1%	1/4W		
R555	1-215-477-00	METAL	220K	1%	1/4W		
R556	1-208-810-11	METAL CHIP	15K	0.50%	1/10W		
R557	1-218-768-11	METAL CHIP	470K	0.50%	1/10W		
R558	1-208-806-11	METAL CHIP	10K	0.50%	1/10W		
R559	1-216-678-11	METAL CHIP	13K	0.50%	1/10W		
R560	1-218-772-11	METAL CHIP	680K	0.50%	1/10W		
R561	1-216-105-91	METAL GLAZE	220K	5%	1/10W		
R562	1-216-073-00	METAL GLAZE	10K	5%	1/10W		
R563	1-215-879-11	METAL OXIDE	47K	5%	1W	F	
R565	1-249-417-11	CARBON	1K	5%	1/4W		
R566	1-216-077-00	METAL GLAZE	15K	5%	1/10W		
R567	1-249-429-11	CARBON	10K	5%	1/4W		
R568	1-216-105-91	METAL GLAZE	220K	5%	1/10W		
R569	1-216-049-91	METAL GLAZE	1K	5%	1/10W		
R570	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W		
R571	1-216-049-91	METAL GLAZE	1K	5%	1/10W		
R572	1-249-429-11	CARBON	10K	5%	1/4W		
R574	1-249-377-11	CARBON	0.47	5%	1/4W	F	
R575	1-216-687-11	METAL CHIP	33K	0.50%	1/10W		
R576	1-249-421-11	CARBON	2.2K	5%	1/4W		
R577	1-249-417-11	CARBON	1K	5%	1/4W		
R578	1-208-806-11	METAL CHIP	10K	0.50%	1/10W		
R579	1-247-891-00	CARBON	330K	5%	1/4W		
R580	1-216-677-11	METAL CHIP	12K	0.50%	1/10W		
R581	1-249-383-11	CARBON	1.5	5%	1/4W	F	
R582	1-215-429-00	METAL	2.2K	1%	1/4W		
R583	1-208-810-11	METAL CHIP	15K	0.50%	1/10W		
R584	1-215-883-11	METAL OXIDE	33	5%	2W	F	
R585	1-249-429-11	CARBON	10K	5%	1/4W		
R586	1-249-397-11	CARBON	22	5%	1/4W	F	
R587	1-215-913-11	METAL OXIDE	220	5%	3W	F	
R588	1-249-417-11	CARBON	1K	5%	1/4W		
R589	1-249-377-11	CARBON	0.47	5%	1/4W	F	
R590	1-249-381-11	CARBON	1	5%	1/4W	F	
R591	1-216-389-11	METAL OXIDE	1	5%	3W	F	
R592	1-216-450-00	METAL OXIDE	82	5%	2W	F	
R593	1-249-377-11	CARBON	0.47	5%	1/4W	F	
R594	1-249-417-11	CARBON	1K	5%	1/4W	F	
R595	1-215-477-00	METAL	220K	1%	1/4W		
R596	1-249-417-11	CARBON	1K	5%	1/4W		
R597	1-249-417-11	CARBON	1K	5%	1/4W	F	
R598	1-249-437-11	CARBON	47K	5%	1/4W		
R599	1-215-882-00	METAL OXIDE	22	5%	2W	F	
R601	1-205-985-21	WIREWOUND	1.5	5%	20W		
R602	1-249-377-11	CARBON	0.47	5%	1/4W	F	
R606 Δ	1-202-882-91	SOLID	560K	20%	1/2W		
R608 Δ	1-215-927-71	METAL OXIDE	47K	5%	3W	F	
R609	1-216-435-11	METAL OXIDE	2.7K	5%	1W	F	
R612	1-247-807-31	CARBON	100	5%	1/4W		
R613	1-207-642-00	WIREWOUND	0.15	10%	3W	F	
R614	1-249-424-11	CARBON	3.9K	5%	1/4W		
R615	1-247-863-91	CARBON	22K	5%	1/4W		
R617	1-249-419-11	CARBON	1.5K	5%	1/4W		
R621	1-249-421-11	CARBON	2.2K	5%	1/4W		
R627	1-249-377-11	CARBON	0.47	5%	1/4W	F	
R631	1-249-417-11	CARBON	1K	5%	1/4W		
R633	1-216-377-11	METAL OXIDE	4.7	5%	2W	F	
R634	1-216-378-11	METAL OXIDE	5.6	5%	2W	F	
R636	1-202-933-61	FUSIBLE	0.1	10%	1/2W	F	
R637	1-249-377-11	CARBON	0.47	5%	1/4W	F	
R651	1-211-874-11	FUSIBLE	0.12	10%	1/2W		
R652	1-211-874-11	FUSIBLE	0.12	10%	1/2W		
R653	1-219-154-11	FUSIBLE	0.12	10%	1/4W		
R654	1-219-154-11	FUSIBLE	0.12	10%	1/4W		
R655	1-219-154-11	FUSIBLE	0.12	10%	1/4W		
R656	1-216-113-00	METAL GLAZE	470K	5%	1/10W		
R658	1-215-445-00	METAL	10K	1%	1/4W		
R659	1-216-349-71	METAL OXIDE	1.0	5%	1W	F	
R660	1-249-420-11	CARBON	1.8K	5%	1/4W		
R661	1-216-081-00	METAL GLAZE	22K	5%	1/10W		
R663	1-249-417-11	CARBON	1K	5%	1/4W		
R664	1-249-417-11	CARBON	1K	5%	1/4W		
R665	1-249-429-11	CARBON	10K	5%	1/4W		
R666	1-249-417-11	CARBON	1K	5%	1/4W		
R667	1-249-417-11	CARBON	1K	5%	1/4W		
R668	1-249-403-11	CARBON	68	5%	1/4W		
R669	1-249-421-11	CARBON	2.2K	5%	1/4W		
R670	1-249-425-11	CARBON	4.7K	5%	1/4W		
R671	1-216-089-91	METAL GLAZE	47K	5%	1/10W		
R672	1-215-925-11	METAL OXIDE	22K	5%	3W	F	
R701	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W		
R702	1-216-073-00	METAL GLAZE	10K	5%	1/10W		
R703	1-216-055-00	METAL GLAZE	1.8K	5%	1/10W		
R704	1-249-417-11	CARBON	1K	5%	1/4W		
R705	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W		
R706	1-216-081-00	METAL GLAZE	22K	5%	1/10W		
R707	1-208-800-11	METAL CHIP	5.6K	0.50%	1/10W		
R708	1-216-073-00	METAL GLAZE	10K	5%	1/10W		
R709	1-216-093-00	METAL GLAZE	68K	5%	1/10W		
R710	1-216-049-91	METAL GLAZE	1K	5%	1/10W		
R711	1-249-429-11	CARBON	10K	5%	1/4W		
R712	1-216-073-00	METAL GLAZE	10K	5%	1/10W		
R713	1-216-073-00	METAL GLAZE	10K	5%	1/10W		
R717	1-249-417-11	CARBON	1K	5%	1/4W		
R721	1-208-812-11	METAL CHIP	18K	0.50%	1/10W		
R722	1-216-081-00	METAL GLAZE	22K	5%	1/10W		
R723	1-216-650-11	METAL CHIP	910	0.50%	1/10W		
R724	1-208-806-11	METAL CHIP	10K	0.50%	1/10W		
R725	1-216-659-11	METAL CHIP	2.2K	0.50%	1/10W		
R800	1-249-377-11	CARBON	0.47	5%	1/4W	F	

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par un tramé et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
		<SPARK GAP>				MISCELLANEOUS	
		SG501 1-519-422-11 GAP, SPARK				*****	
		<TRANSFORMER>				Δ 1-409-975-12 COIL, DEMAGNETIZATION	
		T501 Δ X-4034-327-1 TRANSFORMER ASSY, FLYBACK (NX-4111/J1E4)				1-452-369-41 MAGNET, RING (6P)	
		T502 1-429-828-11 TRANSFORMER, FERRITE (DFT)				1-573-983-31 CONNECTOR (D SUB) (CONNECTOR) 15P (CPD-200SF)	
		T503 1-426-998-11 TRANSFORMER, FERRITE (HST)				Δ 1-558-481-12 CORD, POWER (10A/125V) (CPD-200SF AUS)	
		T504 1-431-056-11 TRANSFORMER, FERRITE (HDT)				Δ 1-765-717-11 CORD SET, POWER (10A/250V) (CPD-200SF ES/CPD-200SFT AEP)	
		T601 1-431-054-11 TRANSFORMER, CONVERTER (SRT)				Δ 1-765-718-11 CORD SET, POWER (10A/125V) (CPD-200SF U/C)	
		<THERMISTOR>				Δ 1-775-706-11 CORD SET, POWER (10A/250V) (CPD-200SFT UK)	
		TH501 1-807-796-11 THERMISTOR				1-774-648-21 ADAPTOR, CONVERSION (CPD-200SFT)	
		TH601 Δ 1-810-509-11 THERMISTOR				1-778-967-21 ADAPTOR, CONVERSION (CPD-200SF)	
		THP602 Δ 1-809-827-11 THERMISTOR, POSITIVE				1-776-975-31 CABLE ASSY(15P DSUB CONNECTOR)	
		<VARISTOR>				Δ B-451-478-71 DEFLECTION YOKE (Y17SAH5-M7)	
		VA601 Δ 1-810-622-11 VARISTOR				Δ B-738-709-92 ITC ASSY (17SASK-R2) (CPD-200SF US/CN)	
		<CRYSTAL>				Δ B-738-709-91 ITC ASSY (17SASK-R3) (CPD-200SF ES)	
		X900 1-567-890-11 VIBRATOR, CRYSTAL				Δ B-738-713-91 ITC ASSY (17SASK-RS1) (CPD-200SF AUS)	
						Δ B-738-605-95 ITC ASSY (17SAFK-R6) (CPD-200SFT AEP, UK)	
						V901 Δ B-738-709-05 PICTURE TUBE (17SASK) (CPD-200SF US/CN, ES)	
						V901 Δ B-738-713-05 PICTURE TUBE (17SASK) (CPD-200SF AUS)	
						V901 Δ B-738-605-05 PICTURE TUBE (17SAFK) (CPD-200SFT AEP, UK)	